## **Sampling Plan for Corrugated Fibre Board Boxes**

## TABLE I

SAMPLING PLAN FOR VISUAL INSPECTION (BASED ON AQL 2.5%)
GENERAL INSPECTION LEVEL II NORMAL

Lo	t Siz	е	Sample Size (n)	Acceptance Number (a)
2	to	8	2	0
9	to	15	3	0
16	to	25	5	0
26	to	50	8	0
51	to	90	13	1
91	to	150	20	1
151	to	280	32	2
281	to	500	50	3
501	to	1200	80	5
1201	to	3200	125	7
3201	to	10000	200	10
10001	to	35000	315	14

## NOTE:

- i) The rejection number (r) will always be one more than the acceptance number (a).
- ii) When the sample size equals or exceeds lot size, do 100% inspection / testing with zero acceptance number.
- iii) Sample size pertaining to 2.5% AQL or around.

**SOURCE:** IS:2500 (Part - I)- 1992 : (Sampling Inspection Tables)

TABLE II

SAMPLING PLAN FOR LABORATORY TESTS
BASED ON AQL 4% INSPECTION LEVEL S – 3

Lot	Size	•	Sample Size (n)	Acceptance Number (a)
up	to	50	3	0
51	to	150	5	0
151	to	500	8	1
501	to	3200	13	1
3201	to	35000	20	2

## NOTE:

- i) The rejection number (r) will always be one more than the acceptance number (a).
- ii) When the sample size equals or exceeds lot size, do 100% inspection / testing with zero acceptance number.
- iii) Inspection level S-3 for chemical & physical tests (individual samples to be tested).
- iv) Sample size pertains to 4% AQL or around.

SOURCE: IS:2500 (Part - I)- 1992 : (Sampling Inspection Tables)